

QUICK INSTALLATION GUIDE



CONTACT

KFA AG
 WEGGIGASSE 40
 P.O. BOX 5224
 6000 LUZERN 5
 SWITZERLAND

PHONE +49 [15 77] 7 82 17 29

E-MAIL STENGELE@KFA.AG

WEB WWW.KFA.AG

KFA2

4-wire TDR-Sensor with single rod, wire rope or coaxial probe for continuous level measurement and point level detection in liquids and light solids, with analog and switching output.

DOCUMENT DESCRIPTION

This quick installation guide gives instructions for mounting, wiring, and basic configuration of KFA2. This will be sufficient to achieve a fully functional sensor in most applications. **For further details and advanced configuration of KFA2, please contact your local distributor or KFA directly.**

INSTALLATION PROCEDURE

