

NivoRadar® Continuous level measuring system NR 3000 Technical information / Instruction manual



Table of contents

		Page
Safety notes/ Technical support		2
Introduction		3
Dimensions		4
Options		5
Technical data		6
Mounting		9
Electrical installation		12
Programming		14
Trouble shooting		18
Menu structure		20
Maintenance		22
Notes for use in Hazardous Locations		23
Disposal		25
Subject to technical change. All dimensions in mm (inches).	We assume no liability for typing errors. Different variations to those specified a	



Please contact our technical consultants.