



### **Table of contents**

		Page
Safety Notes/ T	Technical support	2
Introducion	Applications/ Versions/ Features	3
Technical data	CN 7100	
	Dimensions Electrical data Mechanical data Environmental and Process conditions Approvals	4 5 6 7
Mounting		7
Electrical instal	lation	9
Operation		13
Troubleshooting	g	18
Maintenance		19
Notes for use in	n Hazardous Locations	20

Subject to technical change. All dimensions in mm (inch). We assume no liability for typing errors. Different variations than specified are possible. Please contact our technical consultants.







### Safety notes / Technical support

### Notes

- Installation, maintenance and commissioning may be accomplished only by qualified technical personnel.
- The product must be used only in the manner outlined in this instruction manual.
- This product is intended for use in industrial areas. Operation of this equipment in a residential area may cause interference to several frequency based communications.

### Special attention must be paid to warnings and notes as follows:

#### WARNING

Ŵ	Relates to a caution symbol on the product: A failure to observe the necessary precautions can result in death, serious injury and/or considerable material damage.
	WARNING
	Relates to a caution symbol on the product: Risk of electric shock
	WARNING
l.	A failure to observe the necessary precautions can result in death, serious injury and/or considerable material damage.
	This symbol is used, when there is no corresponding caution symbol on the product.
CAUTION	A failure to observe the necessary precautions can result in considerable material damage.

### Safety symbols

In manual and on product	Description
$\bigwedge$	CAUTION: refer to accompanying documents (manual) for details.
	Earth (ground) Terminal
	Protective Conductor Terminal

### Technical support

Please contact your local supplier (for address see www.uwt.de). Otherwise you can contact:

UWT GmbH	Tel.: 0049 (0)831 57123-0
Westendstr. 5	Fax: 0049 (0)831 76879
D-87488 Betzigau	info@uwt.de
	www.uwt.de







### Introduction

### Applications

CN 7000 is a compact 2-wire capacitance switch for level detection in constricted spaces, applicable in:

- Interfaces, solids, liquids, slurries, and foam
- Foods and pharmaceuticals
- Chemical and petrochemical
- Hazardous areas

#### Versions

- Integral cable version with stainless steel process connection and probe options of PPS or PVDF
- Enclosure version (thermoplastic polyester enclosure) with stainless steel process connection in combination with a PPS or PVDF probe.
- Enclosure version (thermoplastic polyester enclosure) with fully synthetic process connection combined with a PPS probe.

#### Features

- NPT, R (BSPT), G (BSPP) process connections.
- Corrosion resistant construction, PPS, and 316L stainless steel (optional PVDF wetted parts).
- Non-polarized, solid-state switch or relay output (enclosure version with fully synthetic process connection only).











### **Technical data - Dimensions**

CN 7100 Integral Cable version CN 7100 Enclosure version















### Technical data - Electrical data

### Electrical

	Integral cable version or Enclosure version with stainless steel process connection	Enclosure version with PPS process connection
Power supply		
Standard	12 - 33 V DC	12 - 33 V DC
Intrinsically safe	10 - 30 V DC Intrinsically safe barrier required	-
	For ATEX:  U,=30 V  I,=120 mA  P,=1,5 W C,=2,1 nF*  L,=1,3 mH	
	For INMETRO: $U_i$ =30 V $I_i$ =200 mA $P_i$ =1.5 W $C_i$ =2 nF* $L_i$ =1 mH	
	* For an integral cable with a length of more than 1.5m a capacitance of 0.3 nF/ m shall be added	
	For FM/ CSA: see page 12	
Alarm Outputs		
mA	4/ 20 mA or 20/ 4 mA 2-wire current loop detection	4/ 20 mA or 20/ 4 mA 2-wire current loop detection
Solid-state switch (Standard)	30 V DC/ 30 V AC 82 mA max. Limited to 30 V DC/ 16 V AC 82 mA max. in wet locations	-
Solid-state switch (Intrinsically safe)	30 V DC max. Intrinsically safe barrier required. The power supply circuit is infallibly galvanically isolated from the solid-state switch circuit.	-
	For ATEX: $U_i$ =30 V $I_i$ =200 mA $P_i$ =350 mW $C_i$ =0* $L_i$ =0	
	For INMETRO: U <sub>i</sub> =30 V I <sub>i</sub> =200 mA P <sub>i</sub> =1.5 W $C_i$ =2 nF* L <sub>i</sub> =1 mH	
	* For an integral cable with a length of more than 1.5m a capacitance of 0.3 nF/ m shall be added	
	For FM/ CSA: see page 12	
Relay output	-	
- max. switching voltage		60 V DC or 30 V AC; limited to 30 V DC/ 16 V AC in wet locations
<ul> <li>max. switching current</li> <li>max. switching power</li> </ul>		1 A 60 W
Repeatability	2 mm (0.08")	2 mm (0.08")







### Technical data - Mechanical data / Operating conditions

Mechanical			
Common probe/ wetted parts	PPS process connection and PPS sensor or 316L process connection and PPS or PVDF sensor		
	Metal process connection seal: Standard is FKM (e.g. Viton). FFKM (e.g. Kalrez) is optional.		
Integral cable version			
- Integral cable body - Process connection - Connecting cable	316L stainless steel 316L stainless steel, ¾" NPT or R 1" (BSPT), or G 1" (BSPP) 1 m (3.3 ft) of 4 conductor, 22 AWG, shielded, polyester jacket		
Enclosure version			
- Housing - Lid - Process connection	VALOX® (thermoplastic polyester) Transparent thermoplastic polycarbonate (PC) 316L stainless steel, ¾" NPT or R 1" (BSPT), or G 1" (BSPP) or PPS process connection, ¾" NPT or R 1" (BSPT)		
- Wiring	Internal 5-point terminal block 1⁄2" NPT wiring entrance (optional M20 x 1.5" cable entry)		
Environmental			
Ambient temperature	Integral cable version and Enclosure version with stainless steel process connection: -30 to +85°C (-22 to +185°F) -20 to +85°C (-4 to +185°F) with option FFKM seal O-ring		
	Enclosure version with PPS process connection: -10 to +85°C (+14 to +185°F)		
	With ATEX approval: Depending on Surface Temperature and Temperature Class, details see page 22.		
Ingress protection:			
<ul> <li>Enclosure version</li> <li>Integral cable version</li> </ul>	Type 4/ NEMA 4/ IP68 Type 4/ NEMA 4/ IP65, with FM approval limited to "Indoor use"		
Installation category	1		
Pollution degree	4		
Process Conditions			
Relative dielectric constant	1.5 minimum		
Process Temperature	Integral cable version and Enclosure version with stainless steel process connection: -30 to +100°C (-22 to +212°F) -20 to +100°C (-4 to +212°F) with option FFKM seal O-ring		
	Enclosure version with PPS process connection: -10 to +100°C (+14 to +212°F)		
	With ATEX approval: Depending on Surface Temperature and Temperature Class, details see page 22.		
Pressure (vessel)	-1 to 10 bar (146 psi) gauge, nominal		





### Approvals / Mounting

### Approvals

	PPS process connection, enclosure version	Stainless steel process connection, enclosure version and internal cable version
General Purpose	CE, FM, CSA	CE, FM/ CSA, TR-CU
Intrinsically Safe (intrinsic safey barrier required)	-	ATEX II 1G 1/2G 1D 1/2D FM/ CSA Class I, II, III, Div. 1, Gr. A-G INMETRO TR-CU
Marine	-	Lloyds Register of Shipping, Categories ENV1, ENV2 and ENV5
Overfill protection	WHG	WHG

#### Note:

EMC testing was conducted on the CN 7000 metal version while mounted in a metallic vessel and wired using shielded cable. The sensitivity was set by turning sensitivity potentiometer 2 turns counter-clockwise from the set point.

### Mounting

### General Safety Instructions

Installation shall only be performed by qualified personnel and in accordance with local governing regulations.

This product is susceptible to electrostatic shock. Follow proper grounding procedures.


# 

### Additional Safety Instructions for Hazardous Locations

see page 20ff

#### Location

The CN 7000 is normally mounted into the vessel top (high detection alarm) or through the tank wall at the detection level (high or low detection alarm).










### Mounting


### Installation Features and Restrictions

Note: Mounting diagrams apply to intergal cable version and enclosure version.



#### **Multiple Units**

When using multiple units, sensors must be 100 mm apart. Mount diagonally if vertical space is restricted.







### **Electrical installation**

### General Safety Instructions

The DC input terminal shall be supplied from a source providing electrical isolation between the input and output, in order to meet the applicable safety requirements of IEC 61010-1.

A wet location is a location where water or other conductive liquid may be present and is likely to increase the risk of electric shock.



### Additional Safety Instructions for Hazardous Locations

see page 20 and following pages









### **Electrical installation**

### Integral Cable Version




#### Operation with solid state switch/ relay



Shield is internal connected to ground. It is recommended to use a shielded cable for stable measurement.

red/ black	white/ white	
Supply: 12 - 33V DC 10 - 30V DC intrinsic safe* Polarity determines output logic, see table below	Output: Solid state switch* Observe protection (see below). Max. 30 V DC/ 30 V AC, 82 mA Limited to 30 V DC/ 16 V AC, 82 mA in wet locations	
* For intrinsic safe operation an intrinsic safety barrier is required		
Ratings U <sub>i</sub> I <sub>i</sub> P <sub>i</sub> C <sub>i</sub> L <sub>i</sub> of power supply and solid state switch: see page 5		

#### Operation with 4/ 20 mA loop




Shield is internal connected to ground. It is recommended to use a shielded cable for stable measurement.

#### Supply: 12 - 33V DC 10 - 30V DC intrinsic safe\* Polarity determines output logic, see table below \* For intrinsic safe operation an intrinsic safety barrier is required. Ratings U<sub>i</sub> I<sub>i</sub> P<sub>i</sub> C<sub>i</sub> L<sub>i</sub> of power supply: see page 5

Rmax = (Vsupply -12 V)/ 20 mA Example: 24 V supply allows Rmax of 600 Ohms

#### **Protection of Solid State Switch**

Observe a Protection diode in case of connecting an external relay to the Solid state switch



Protection diode

#### **Output logic**

Yellow LED	0		÷.	
Status	FSL	FSH	FSL	FSH
Supply polarity (cable colour)	red <b>+</b> black -	red - black +	red + black -	red - black +
Red LED	0	÷.	-¢-	0
Solid state switch		E		<u> </u>
4/ 20 mA loop	4 mA	20 mA	20 mA	4 mA

FSL = Fail safe low FSH = Fail safe high










### **Electrical installation**

### **Enclosure Version**






#### Operation with solid state switch/ relay




Terminal 3 is internal connected to ground. It is recommended to use a shielded cable for stable measurement.

Terminal 1, 2	Terminal 3	Terminal 4, 5	
Supply: 12 - 33 V DC 10 - 30 V DC intrinsic safe* Polarity determines output logic, see table below	cable shield connection connect to ground	Output: Solid state switch * Present with stainless steel process connection. Observe protection (see below). Max. 30 V DC/ 30 V AC, 82 mA, limited to 30 V DC/ 16 V AC, 82 mA in wet locations Relay Present with PPS process connection. Intrinsic Safety operation not available. Max. 60 V DC or 30 V AC; limited to 30 V DC/ 16 V AC in wet locations, Max. 1 A, 60 W	
* For intrinsic safe operation an intrinsic safety barrier is required Ratings U, I, P, C, L of power supply and solid state switch: see page 5			

#### Operation with 4/20 mA loop



Rmax = (Vsupply -12 V)/ 20 mA Example: 24 V supply allows Rmax of 600 Ohms



# It is recommended to use a shielded cable for stable measurement.

#### **Output logic**

Yellow LED	0		3	¢-
Status	FSL	FSH	FSL	FSH
Supply polarity (Terminal)	1 <b>+</b> 2 <b>-</b>	1 - 2 +	1 <b>+</b> 2 <b>-</b>	1 - 2 +
Red LED	0	¢	¢	0
Solid state switch	<u> </u>	T	T	<u> </u>
4/ 20 mA loop	4 mA	20 mA	20 mA	4 mA


FSL = Fail safe low FSH = Fail safe high

# SOLUTIONS

#### CN 7000 d

#### Protection of Solid State Switch

Observe a Protection diode in case of connecting an external relay to the Solid state switch








### **Electrical installation**










### Operation

### Settings



#### Output logic (Failsafe High/ Failsafe Low)

See table on page 10 and 11.







### Operation

#### **Switchpoint Adjustment**

Select the switchpoint adjustment according to the application as follows:

Application	Material	Adjustment conditions
General	<ul><li>Dry solids</li><li>Low viscosity liquids</li></ul>	Sensor uncovered
Demanding	<ul><li>Hygroscopic/ wet solids</li><li>High viscosity and high conductivity liquids</li></ul>	Sensor immersed and then uncovered, retaining max. possible material buildup
Interface detection	<ul> <li>Ignoring liquid A/ detecting liquid B</li> <li>Ignoring foam/ detecting liquid</li> </ul>	Immerse sensor in liquid A or foam

#### General applications

1. Ensure material level is well below the probe	The unit will calibrate	e to an uncovered probe.	
2. Adjust switchpoint with poti	If LED L1 (yellow) is ( turn poti clockwise u Turn poti counter clo just stops glowing.	until L1 is ON.	Poti $L_{yellow}$ $\bigcirc$ $-\downarrow$ $-$ $\bigcirc$ $-\downarrow$ $-$ $\bigcirc$ $-\downarrow$ $-$
Switchpoint adjustment is finished			







### Operation

Demanding applications

1. Ensure material level is well above the probe						
2. Ensure material level is well below the probe		tant that as mu		ildup		
3. Adjust switchpoint with poti					Poti	L1 yellow
		yellow) is OFF, lockwise until L	1 is ON.			
	Turn poti o just stops	counter clockwi glowing.	se until L1			
	Turn poti f	urther counter (	clockwise:			
	Dieleo of ma	ctric constant terial	Number of turns		$\bigcirc)$	
		<2	1⁄4			
		2 4	1/2	-		
		>4	1	]		
	Depending switchpoir	g on the applica nt the number o	ation and the re f turns can be	equired varied.		
Switchpoint adjustment is finished						





### Operation

#### Interface detection

Level limit switch Series CN 7000 Technical Information / Instruction manual



1. Immerse probe in liquid A or in foam which should NOT be detected	Ensure that liquid A or foa NOT be detected) is cove Liquid A or foam must har <b>constant</b> than liquid B, w be detected.	ring the probe. ve a <b>lower dielectri</b>	c Liquid A or foam
2. Adjust switchpoint with poti	If LED L1 (yellow) is OFF, turn poti clockwise until L Turn poti counter clockwi		Poti yellow
	just stops glowing. Turn poti further counter of Dielectric constant of material <2 2 4 >4 Depending on the applica	Number of turns 1/4 1/2 1 ation and the require	
	switchpoint the number o Note: The sensitivity is now s or foam is NOT detected.	setted thus that liquid /	
3. Immerse probe in liquid B which should be detected	Ensure that liquid B (whic be detected) is covering t L1 should glow.		Liquid A or foam Liquid B
Switchpoint adjustment is finished			







### Operation

Measurement through non metal vessel wall

1. Ensure material level is well below the probe	The unit will calibrate to an uncovered probe.	non metal vessel wall
2. Adjust switchpoint		L1
with poti		Poti yellow
	If LED L1 (yellow) is OFF,	
	turn poti clockwise until L1 is ON.	()) 🔍 -Q-
	Turn poti counter clockwise until L1	
	just stops glowing.	(S) - Q- (Ø)
	Turn poti counter clockwise another ca. ¼ turns.	ca. ¼ turns
	Depending on the application and the required switchpoint the number of turns can be varied.	$\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{\mathbf{$
3. Ensure material level is	L1 should glow.	
well above the probe		
		L1 yellow
Switchpoint adjustment is		
finished		







### Troubleshooting

Symptom	Cause	Action
Green LED off	Proper power not applied to device	Check power source
	Power range must equal 12 to 33 V DC at all times (10 to 30 V DC for IS versions)	Minimum 12 V DC on the terminals when the signal current is 20 mA (minimum 10 V DC for IS versions)
Green LED off, with proper supply	Defective component in device.	Contact distributor
	Connector came loose.	Refasten connector
Green LED on and Yellow LED on while not responding	Proper power not applied to device.	Check power source
to product and/ or adjustment	Power range must equal 12 to 33 V DC at all times (10 to 30 V DC for IS versions)	Minimum 12 V DC on the terminals when the signal current is 20 mA (minimum 10 V DC for IS versions)
Hysteresis region too great	Proper power not applied to device.	Check power source
	Power range must equal 12 to 33 V DC at all times (10 to 30 V DC for IS versions)	Minimum 12 V DC on the terminals when the signal current is 20 mA (minimum 10 V DC for IS versions).
Unequal current in red and black wire	Loop circuitry is DC biased w.r.t. ground	Correct loop circuitry.
black wire	Black wire exceeds +36 V DC against ground	Remove cause of voltage on the red wire and/or bias
Yellow LED won't come on or off	Defective component in device	Contact distributor
Too much current in loop	Supply voltage too high	Ensure power range equals 12 to 33 V DC at all times (10 to 30 V DC for IS versions).
Red LED lights opposite to the Yellow LED when this is not meant to happen	Incorrect polarity on red and black loop terminals	Reverse polarity on loop terminals
Red and Yellow LEDs are blinking fast	Proper power not applied to device.	Check power source
	Power range must equal 12 to 33 V DC at all times (10 to 30 V DC for IS versions)	Minimum 12 V DC on the terminals when the signal current is 20 mA (minimum 10 V DC for IS versions)
Red and Yellow LEDs are blinking while switching	Proper power not applied to device.	Check power source
Sinning while Switching	Power range must equal 12 to 33 V DC at all times (10 to 30 V DC for IS versions)	Minimum 12 V DC on the terminals when the signal current is 20 mA (minimum 10 V DC for IS versions)
Solid state contact does not follow status Red LED	Defective component in device. Probable cause: wrong wiring in this circuit.	Contact distributor







## **Troubleshooting / Maintenance**

Relay state contact does not follow status Red LED	Proper power not applied to device	Check power source
	Power range must equal 12 to 33 V DC at all times	Minimum 12 V DC on the terminals when the signal current is 20 mA
	Defective component in device.	Contact distributor
Yellow LED is lit while probe is not covered	May indicate significant product buildup.	Rotate sensitivity potentiometer further CCW (counter clockwise) Check sensor tip

### Maintenance

The CN 7000 requires no maintenance or cleaning.







### Notes for use in Hazardous Locations

### Use of this Manual

For use and assembly, refer to the instructions in this Manual. It does contain all instruction as required by ATEX Directive 2014\_34\_EU, Annex II, 1/0/6 and Ordinance INMETRO nº 179/2010

#### General notes

Refer to appropriate certificate for application in specific hazardous environment.

The equipment has not been assessed as a safety related device (as referred to by Directive 2014\_34\_EU Annex II, clause 1.5).

The certificate numbers have an 'X' suffix, which indicates that specific condition of use apply. Those installing or inspecting this equipment must have access to the certificates.

# Qualification of personnel / Servicing / Repair

Installation and inspection of this equipment shall be carried out by suitably trained personnel in accordance with the applicable code of practice (ABNT NBR IEC/EN 60079-14 and ABNT/NBR IEC/EN 60079-17 in Europe).

Repair of this equipment shall be carried out by suitably trained personnel in accordance with the applicable code of practice (e.g. ABNT NBR IEC/EN 60079-19 within Europe).

Components to be incorporated into or used as replacements in the equipment shall be fitted by suitably trained personnel in accordance with the manufacturer's documentation.

Turn off power before servicing any device (the transmitter is in operation when the power supply is switched on). In case of removing the unit from vessel, take care of process pressure and material passing the opening.

### ATEX: Certificates / List of Standards

See www.uwt.de for the latest certificates

See EU - Declaration of conformity for the list of standards valid for ATEX certificates

### ATEX: Year of manufacturing

Marking on the name plate is done according to IEC 60062 as follows:

Year of manufacturing	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029
Marking code	K	L	Μ	Ν	Р	R	S	Т	U	V	W	Х

### ATEX: Ex-Marking

Devices with ATEX approval are marked on the name plate as follows:







### Notes for use in Hazardous Locations

# ATEX: Permitted zones for installation

Devices can be installed as follows:

### Specific condition of use

#### Electrostatic charge

For applications in explosive atmospheres caused by gases, vapours or mists or air/dust mixtures, precautions shall be taken to minimize the risk from electrostatic discharge or propagating brush discharges of non metallic parts of the enclosure.

Process and ambientPlease check the ambient and process temperatures page 22 for the specific configurationtemperatureyou are about to use or install.

# Warnings for installation

Intrinsically safe supply	For intrinsically safe models, power must be supplied from an Intrinsically Safe power source, otherwise protection is no longer guaranteed.
Process pressure	The device construction allows process over-pressure up to 10 bar (146 psi). This pressure is allowed for test purposes. The definition of the Ex approvals are only valid for a container-over-pressure between -0.2 +0.1 bar (-2.9 +1.45 psi). For higher or lower pressures the approvals are not valid.
Chemical resistance against the medium	If the equipment is likely to come into contact with aggressive substances, then it is the responsibility of the user to take suitable precautions that prevent it from being adversely affected, thus ensuring that the type of protection is not compromised. Aggressive substances: e.g. acidic liquids or gases that may attack metals, or solvents that may affect polymeric materials. Suitable precautions: e.g. establishing from the material's data sheet that it is resistant to specific chemicals.








### Notes for use in Hazardous Locations

- Ambient and process temperature range,
- max. Surface Temperature and Temperature Class

#### ATEX:

Ambient temperature range	Process temperature range	Max. Surface temperature (EPL Da/Db)	Temperature class (EPL Ga)
-30 to +40°C (-22 to +104°F)	-30 to +75°C (-22 to +167°F) (1)	T <sub>200</sub> 85°C	Т6
-30 to +85°C (-22 to +185°F)	-30 to +85°C (-22 to +185°F) (1)	T <sub>200</sub> 130°C	T4



(1) With option FFKM O-ring seal: Lower process temperature limited to -20°C (-4°F)

#### **INMETRO:**

Ambient temperature range	Process temperature range	Max. Surface temperature	Temperature class
-40 to +40°C (-40 to +104°F)	-40 to +40°C (-40 to +104°F)	62 °C	T6
-40 to +85°C (-40 to +185°F)	-40 to +100°C (-40 to +212°F)	107 °C	T4

#### FM:

Ambient	Process	Temperature
temperature range	temperature range	class
-30 to +85°C (-22 to +185°F)	-30 to +100°C (-22 to +212°F)	T4

#### CSA:

Ambient	Process	Temperature
temperature range	temperature range	class
-40 to +85°C (-40 to +185°F)	-40 to +100°C (-40 to +212°F)	T4

